

Пульт дистанционного управления универсальный

ДУ-15 О

TYPE: **D018B001**

 **PHILIPS**



Описание:

Этот пульт подходит к следующей аппаратуре:

RC0301/01, RC0732/01, RC0764/01, RC0770/01, RC10, RC19039001/01, RC19042001/01, RC1904/01, RC19329002/01, RC19335003/01, RC19335005/01, RC19335010/01, RC2000, RC2529/01, RC2563/01, RC2575/01, RC2582/01, RC2829/01, RC283501, RC7954, RC7959, RC8201, RC8205, RC8205/01, RC9820BK, SAA3010, BR5502, RP106, RP420, RP520, RC2143, RC2149, RC5536, RC-5R/T, RC2034301/01, RC0701, P6-P1, NZS2040, NZS2050, RC647340, RC3010, RC-6, BP6, ST86563, SRU8434, PH308, PH309, PH313, PH916, RC19036002, RC19042004, RC19042011, RC19042013, RC19042018/01, RC19335001, RC19335004, RC2001, RC2006, RC2030, RC2031, RC2048, RC2080, RC25109/01, RC2512, RC2521, RC2525, RC2525/01, RC2533, RC2541, RC2585/01, RC2591, RC2592, RC283207/01, RC283502/01, RC283510/01, RC2882, RC4301, RC4337, RC4361, RC5410, RC5536, RC5903, RC5915, RC5918, RC5991, RC7502, RC7599, RC7801, RC7808, RC7815, RC7848, RC7854, RC7943, RC7952, RC8207B, RC8207S, RC8211, RC8922, RC8925, RC8926/01, RC8927, RC9057, RC9067, RC9500, RC9133, HE888, PHILIPS PIP, RM-PH07